

Samsung	Galaxy S9/S9 Plus	YotaDevices	YotaPhone	Apple	iPhone 4S
Samsung	Galaxy S8/S8 Plus	YotaDevices	YotaPhone2	Apple	iPhone 5/5C
Samsung	Galaxy S7			Apple	iPhone 5S
Samsung	Galaxy A7 (2017)			Apple	iPhone 6/6 Plus
Samsung	Galaxy A5 (2017)			Apple	iPhone 6S/6S Plus
Samsung	Galaxy A3 (2017)			Apple	iPhone SE
Samsung	Galaxy A5 (2016)			Apple	iPhone 7/7 Plus
Samsung	Galaxy A3 (2016)			Apple	iPhone 8/8 Plus
Samsung	Galaxy J7 (2016)			Apple	iPhone X
Samsung	Galaxy J5 (2016)			Apple	iPhone XS/XS Max
Samsung	Galaxy Tab S4 8.0/9.7			Apple	iPhone Xr
Samsung	Galaxy Tab S3 8.0/9.7			Apple	iPad 2
Samsung	Galaxy Tab S2 8.0/9.7			Apple	iPad 3
Samsung	Galaxy Tab A 10.1			Apple	iPad 4
Samsung	Galaxy Tab A 7.0/8.0			Apple	iPad Air
Samsung	Galaxy Tab E 9.6			Apple	iPad Air 2
Samsung	Galaxy Note 8			Apple	iPad (2017)
Samsung	Galaxy Note 9			Apple	iPad (2018)
Samsung	Galaxy Tab 3 Lite 7.0			Apple	iPad Pro 9,7
Samsung	DeX Station			Apple	iPad Pro 10,5
Samsung	DeX Pad			Apple	iPad Pro 12,9
Samsung	DeX Cable			Apple	iPad Pro 11
				Apple	iPad Air (2019)
				Apple	iPad mini 2
				Apple	iPad mini 3
				Apple	iPad mini 4
				Apple	iPad mini 5