


MO1003

Проверка работы Рутокен в OS X

Для проверки работоспособности ключа Рутокен необходимо открыть **Terminal**. Чтобы его открыть, можно использовать значок поиска и в появившемся окне в строке поиска начать вводить terminal



В открывшемся окне наберите команду **pcscstest**, после чего два раза введите единицу.

```
aktiv — -bash — 81x43
Last login: Wed Jun 21 17:00:07 on ttys000
Mac-mini-aktiv:~ aktiv$ pcscstest
MUSCLE PC/SC Lite Test Program

Testing SCardEstablishContext : Command successful.
Testing SCardGetStatusChange : Command successful.
Please insert a working reader : Command successful.
Testing SCardListReaders     : Command successful.
Reader 01: Aktiv Rutoken ECP
Enter the reader number      : 1
Waiting for card insertion

Testing SCardConnect         : Command successful.
Testing SCardStatus          : Command successful.
Current Reader Name          : Aktiv Rutoken ECP
Current Reader State         : 0x54
Current Reader Protocol      : 0x1
Current Reader ATR Size      : 15 (0xf)
Current Reader ATR Value     : 3B 8B 01 52 75 74 6F 6B 65 6E 20 44 53 20 C1
Testing SCardDisconnect     : Command successful.
Testing SCardReleaseContext  : Command successful.
Testing SCardEstablishContext : Command successful.
Testing SCardGetStatusChange : Command successful.
Please insert a working reader : Command successful.
Testing SCardListReaders     : Command successful.
Reader 01: Aktiv Rutoken ECP
Enter the reader number      : 1
Waiting for card insertion

Testing SCardConnect         : Command successful.
Testing SCardStatus          : Command successful.
Current Reader Name          : Aktiv Rutoken ECP
Current Reader State         : 0x54
Current Reader Protocol      : 0x1
Current Reader ATR Size      : 15 (0xf)
Current Reader ATR Value     : 3B 8B 01 52 75 74 6F 6B 65 6E 20 44 53 20 C1
Testing SCardDisconnect     : Command successful.
Testing SCardReleaseContext  : Command successful.

PC/SC Test Completed Successfully !
Mac-mini-aktiv:~ aktiv$
```

Если в строке "**Current Reader Name**" отображается название модели Рутокен, это означает, что носитель определяется корректно в операционной системе OS X.