
DM1007

Rutoken is not visible in the "Rutoken Control panel". More than 10 Smart Card devices.

The drivers were installed successfully, but Rutoken is not visible in the "Rutoken Control Panel".




First solution


Check "Smart Card devices" in the "Device Manager" (Start - Control Panel - Device Manager)

If you have Windows 7, 8 or 10, then in case of 10 or more Smart Card devices you will get an internal error, all devices (Smart Cards and USB-tokens) will not work properly.

If you don't use some of them, we recommend to delete related program clients and/or drivers.

If it is not possible, then you can lower the quantity of Smart Card readers in the "Device Manager" (but don't delete drivers for these devices).


Device Manager
File Action View Help
WIN-14C6M3O7L3L
Batteries
Computer
Disk drives
Display adapters
DVD/CD-ROM drives
Floppy disk drives
Floppy drive controllers
Human Interface Devices
IDE ATA/ATAPI controllers
Keyboards
Memory devices
Mice and other pointing devices
Monitors
Network adapters
Portable Devices
Ports (COM & LPT)
Processors
Smart card readers
Aktiv Co. IFD Handler
Aktiv Co. IFD Handler
Aktiv Co. IFD Handler
Aktiv Co. IFD Handler
Aktiv Co. IFD Handler
Aladdin IFD Handler
Aladdin IFD Handler
Aladdin VR Handler
Microsoft Usbccid Smartcard Reader (WUDF)
Microsoft Usbccid Smartcard Reader (WUDF)
Microsoft Usbccid Smartcard Reader (WUDF)
> 10
Sound, video and game controllers
Storage controllers
System devices
Universal Serial Bus controllers



When there will be 10 or less Smart Card readers (and USB-tokens), all of them will be functioning properly.

Second solution

You should reinstall Rutoken drivers with another number of virtual Smart Card readers.

Rutoken drivers add 3 virtual readers "Aktiv Co IFD Handler" by default. They are required for Rutoken S USB-tokens, but you probably don't need all of them.

If you are using Rutoken S, you need at least 1 virtual reader (or more, if you use them simultaneously). If you are using Rutoken Lite/Rutoken ECP - you don't need them at all.

To lower the quantity of virtual readers:

1. Uninstall Rutoken Drivers (via "Control Panel")
2. Download the latest drivers
3. Save the installer to the convenient folder (ex.: "C:\")
4. Launch "Command Promt" as Administrator. («Start -> All Programs -> Accessories -> Command Prompt», click right mouse button and choose "run as Administrator")
5. Launch installer with a VIRTRDR=X parameter, where X is the required number of virtual readers (ex.: c:\rtDrivers.exe VIRTRDR=1)